

# ECLIPSEFS

## DMX CONTROL

Channel													FUNCTION	DMX Value
Tun	3200K	5400K	6500K	1CH	2CH	3CH	RGB	4CH RGLB	5CH	5CH RGLB	8CH	13CH		
1	1	1	1	1	1	1			1	1	1	1	<b>Dimmer</b> Dimmer(Close to Open)	000 - 255
									2			2	<b>Dimmer fine</b> Dimmer fine 0->100%	000 - 255
					2	2				3			<b>CTC Preset</b> 2000K 2000K->2700K 2700K->3200K 3200K->4200K 4200K->5600K 5600K->8000K 8000K->10000K	000 - 025 026 - 063 064 - 101 102 - 139 140 - 177 178 - 215 216 - 255
									4				<b>CTC Fine</b> CTC Fine	000 - 255
2							1	1		2	2	3	<b>Red</b> Red 0->100%	000 - 255
												4	<b>Red fine</b> Red fine 0->100%	000 - 255
3							2	2		3	3	5	<b>Green</b> Green 0->100%	000 - 255
												6	<b>Green fine</b> Green Fine 0->100%	000 - 255
4							3	3		4	4	7	<b>Blue</b> Blue 0->100%	000 - 255
												8	<b>Blue fine</b> Blue Fine 0->100%	000 - 255
5								4		5	5	9	<b>Lime</b> Lime 0->100%	000 - 255
												10	<b>Lime fine</b> Lime Fine 0->100%	000 - 255
											6	11	<b>CTC Preset</b> No function 2000K 2000K->2700K 2700K->3200K 3200K->4200K 4200K->5600K 5600K->8000K 8000K->10000K	000 001 - 025 026 - 063 064 - 101 102 - 139 140 - 177 178 - 215 216 - 255
											7	12	<b>Shutter Function</b> Normal Shutter Functions Strobe effect slow to fast	000 - 003 003 - 255
						3			5		8	13	<b>Dimmer Fade</b> 0->100%	000 - 255